

## INSTALLING EXTERNAL DEVICE (STROBE) TO NYAD ANALYZER

- 1) To install an external device such as a strobe light to the Nyad analyzer the following are required:
  - a) External Power Supply (Customer to supply)
  - b) Strobe light 12V (Customer to supply)
- 2) After wiring is complete, Alarm 2 must be set identical to Alarm 1. For example, if AL1 is set at 10, AL2 must be set at 10.

### Wiring Diagram to Relay Contact 2

